



WARNING :
NEVER SPIN THE SHAFT
WITH THE BLACK EARTH WIRE REMOVED !

To Test for Spark :
Tape the Spark Plug(s) to the side
of the Magneto Casing.
Spin the shaft with fingers
A good spark should occur every time.

This Diagram shows
Trigger Rotor position for :
_____° Advance with
engine positioned at TDC
on firing stroke.

**HIGH ENERGY ELECTRONIC IGNITION SYSTEM 3000Q
FOR PAL MAGNETO ***

Including Automatic Retard for Easy Starting

* The Pal Magneto is entirely dismantled, modified and rewired to work with the 3000Q System